



Alternative
sawn joint seat

Typical Appearance of Square Rule Framing, after c. 1820